


DB25 DB9 Signal (relative to PC)

| I | 2 | 3 | xmit |
|---|------------------|--------|---------|
| I | 3 | 3 2 | receive |
| I | 2 3 4 5 | 7 | rts |
| I | 5 | 8 | cts |
| I | 6 | 6 | dsr |
| I | 7 | 5 | gnd |
| I | 20 | 4 | dtr |
| ١ | 8 | 1 | dcd |

- 1) Connect wire from pin 4 to pin 6.
- 2) Put pin 4 of opto into pin 6 of DB9 (opto pin 3 is on outside of connector)
- 3) Put 2.2K into pin 3 of DB9. Run resistor lead around pin 3 of opto and back to pin 2 of DB 9. Solder to pin 3 of opto.

Isolated, +/- RS232



Non-Isolated, 0-5v RS232

| FarmTek/ | Title: Timer Console to PC Interface Cable | | | | |
|--------------------------------------|--|---------|-----------|--------------|--|
| FarmTek, Inc. 1000-D Hwy 78 North | Revision: | 2.0 | Engineer: | Mike Douglas | |
| Wylie, TX 75098 (972) 429-0947 | Date: | 3/24/94 | Approved: | | |